

OPERATION/MAINTENANCE MANUAL

PORTABLE TRITIUM MONITOR

MODEL RS400-HTO  
with Alkaline Battery Option



**OVERHOFF TECHNOLOGY CORPORATION**  
**1160 US ROUTE 50, MILFORD, OHIO, USA**

## DECLARATION OF CONFORMITY

We, The Manufacturer: OVERHOFF TECHNOLOGY CORPORATION  
1160 U.S. Route 50, Milford, Ohio, 45150

Declare that the following equipment:

Description: Tritium in Air Monitor, Portable Model Series 400,  
Model Designations: 400SBDyC, RS400, RS400-HTO, 400AC, 400AC-WP

### Complies with the following Council Directive (s):

RoHS Directive 2001/65/EU on the Restriction of the Use of certain Hazardous Substances in Electrical and Electronic Equipment

Electromagnetic Compatibility Directive (EMC) 89/336/EEC and amending directives 91/263/EEC, 92/31/EEC, 93/68/EEC

Low Voltage Directive 73/23EEC, and amending directive 93/68/EEC

---

### The following standard(s) were used to verify compliance with Annex I:

EN61326	Class A, Radiated/Conducted Emissions Limits
EN61000-3-2	Conducted Emissions, Equipment Class A
EN61000-3-3	Conducted Emissions (Voltage Fluctuations)
EN61000-4-2 Level 2	Electrostatic Discharge Immunity
EN61000-4-3	Electromagnetic Field Immunity
EN61000-4-4	Electrical Fast Transient Immunity
EN61000-4-5	Surge Immunity
EN61000-4-6	RF Conducted Immunity
EN61000-4-11	Voltage Dips Immunity

Pertinent LVD section of:


BS EN 61010-1	Safety requirements for electrical equipment for measurement, control and laboratory use, Part 1: General requirements: 2001
---------------	--

---

Technical information is maintained at: Overhoff Technology Corporation  
1160 U.S. Route 50, Milford, Ohio 45150

**We, the undersigned, hereby declare that the product(s) specified above fulfills all relevant portions of Annex I in the Low Voltage, EMC and RoHS Directives. This declaration of conformity is issued under the sole responsibility of the manufacturer.**

Full Name: Dell Williamson

Signature: 

Position: Vice President of Operations

Date: 20 September 2018

P.O. Box 182, 1160 U.S. Route 50, Milford, Ohio, 45150-9705 USA

Telephone 513 248 2400 Facsimile 513 248 2402

e-mail [sales@overhoff.com](mailto:sales@overhoff.com)

website: <http://www.overhoff.com>

## SAFETY NOTICE

This Tritium Monitor has been designed and tested in accordance with EN 61010-1. To ensure that the monitor is used safely, follow all safety and operating instructions in this manual. If the monitor is not used as described in this manual, the safety features of the monitor might be impaired.

- Do not use the monitor unless it is fully assembled, housed inside the case secured with the screw fasteners it was supplied with.
- Turn off the power and remove the plug connection from the AC power converter before removing batteries.
- Make sure the battery covers are properly closed and secured.
- Remove the battery from the monitor if the monitor is to be stored for long periods.
- This instrument has not been designed for indiscriminate opening or disassembly of the internal parts. The bias voltage batteries are always connected to the ionization chamber cans, even when the instrument is switched OFF. The electronics contains highly sensitive semiconductors which are destroyed by even the slightest electrostatic discharge
- Not suitable for use in wet locations
- Not suitable for use in explosion hazard environments
- Refer to instruction label when connecting to the external jack for supplementary power input. DO NOT EXCEED 3.5VDC! Use only the AC power converter that was supplied with the monitor.

## SYMBOLS

The following international symbols are used with this manual and equipment:



Important Safety Information in Manual



DC (direct current)

## TABLE OF CONTENTS

<u>SECTION</u>		<u>PAGE</u>
1.0.	INTRODUCTION	1
2.0.	TECHNICAL SPECIFICATIONS	2
3.0.	CIRCUIT DESCRIPTION	4
4.0.	CONFIGURATION	6
5.0.	OPERATION	7
6.0.	CALIBRATION	10
7.0.	MAINTENANCE	12
8.0.	SERVICE	13
9.0.	WARRANTY	13
10.0.	REPLACEABLE PARTS	14
	FIGURE 1, FRONT PANEL CONTROLS	15
	FIGURE 2, HOSE BARB CONNECTION	16
	FIGURE 3, OUTPUT CONNECTIONS	17
	DRAWING, J2 OUTPUT CABLE	
	DRAWING, FUNCTIONAL BLOCK DIAGRAM	
	DRAWING, GENERAL ARRANGEMENT MODEL RS400-HTO WITH OPTIONAL ALKALINE BATTERIES	
	WIRING DIAGRAM, MODEL RS400-HTO WITH OPTIONAL FOR ALAKINE BATTERIES	

## 1.0. INTRODUCTION

The Model RS400-HTO portable tritium monitor is a small, high sensitivity, hand held, battery operated fully gamma compensated survey meter with an RS232 serial data output. The instrument case is constructed of light weight aluminum. A handle is attached for hand held survey use. The instrument will measure tritium in its elemental and oxide form or can be configured to measure oxide form only.

**Note: This special version of the Model RS400-HTO has the Alkaline Battery Option.**

## 1.1. PHYSICAL DESCRIPTION

The Model RS400-HTO uses four identical ionization chambers arranged in a cruciform pattern. Two ionization chambers, with a total volume of 400 cc, are used for measurement; the other two chambers serve for gamma compensation.

The sample stream is drawn through the ionization chambers by means of a small rotary vane pump, which is always plumbed at the outlet of the furthest down stream ionization chamber. Attaching a good quality particulate filter ahead of the instrument sampling inlet prevents entry of dust particulates.

A large easy to read liquid crystal digital panel meter with a range from 1 to 19,999  $\mu\text{Sv/hr}$  is used for measurement display.

Other units of measurement, such as MPCa, MBq/m<sup>3</sup> and  $\mu\text{Ci/m}^3$  or others may be specified by the user at time of requesting a unit. The instrument exhibits a basic sensitivity of the order of 2  $\mu\text{Sv/hr}$ , which it is able to attain due to the fact that it is immune to response to both radon and cosmic ray noise.

A pair of "D" size batteries supplies power. While it is recommended that Alkaline cells be used, the instrument will also operate with any type of D-cell batteries, although operating duration maybe vary. Onset of battery depletion is signaled by illumination of an LED located next to the meter face. An external power supply can be used by attaching to a small receptacle the side of the instrument case. The same LED also signals red when the high voltage power supply (HVPS) used for ionization chamber bias has a malfunction.

### **DO NOT SUBSTITUTE, use only the recommended external power supply**

A ten-position alarm level stepped attenuator, adjustable over partial scale (2 to 1,000  $\mu\text{Sv/hr}$ ) is located on the front panel. An OFF position is included. An acoustic signaler emits a steady tone if the measurement exceeds the set point. An intermittent tone is heard if the sample air flow has been interrupted. The acoustic alarm is silenced by a "MUTE" push button. The alarms are non-latching.

External connections for RS232 serial data output has been provided.

For measurements of tritium in the presence of other radioactive gases by means of ionization chambers appears, at first glance, to be impossible. However, recognizing that tritium oxide is water, a tritium specific measurement is attained through the use of differential ionization chambers with an HTO removal dryer interposed between the two ionization chambers. Since all radioactive components, with the exception of the tritium component is present in both the upstream and downstream ionization chamber, the net (subtracted) ionization current is now proportional only to the tritium oxide.

For example: A cartridge filled with disposable desiccant can be interposed between the measurement and compensation ionization chambers will yield a net measurement response only to tritium oxide;  $\text{HTO} + \text{other nuclide} - (\text{other nuclide}) = \text{HTO}$

Gas flow connections are made externally to the instrument by appropriate attachment of flexible plastic hose. See Figure 2.

## 2.0. TECHNICAL SPECIFICATIONS, MODEL RS400-HTO

MEASUREMENT DISPLAY	4 1/2 digit LCD
MEASUREMENT RANGE	1 to 19,999 $\mu\text{Sv/hr}$ NOTE: Conversion factor according to ICRP-68 Table C1 where: $1 \mu\text{Sv/h} = 3.09\text{E}4 \text{ Bq/m}^3 = 0.835 \mu\text{Ci/m}^3$
SENSITIVITY	2-3 $\mu\text{Sv/hr h}$ ( $2 \mu\text{Ci/m}^3$ )
ACCURACY	$\pm 10\%$
GAMMA COMPENSATION	multiple chambers in a cruciform pattern to reduce errors due to external gamma radiation Gamma response less than 0.2 $\mu\text{Sv/hr}$ per mR/hr for any field direction.
RESPONSE RATE	30 seconds to reach 90% of final reading,
NOISE LEVEL	$\pm 2 \mu\text{Sv/hr}$ 1 S.D. (10 second electronic time constant)
ZERO STABILITY	$\pm 2 \mu\text{Sv/hr}$ after 3 minutes (or less) warm-up
ALARM (ACOUSTIC)	<ol style="list-style-type: none"><li>ten position stepped attenuator set point for signal alarm 2 to 1,000 <math>\mu\text{Sv/hr}</math>, steady tone. OFF position included.</li><li>low flow produces an intermittent tone</li><li>Mute switch silences audible tone</li></ol>
ALARM (VISUAL)	LEVEL: red LED; when tritium level exceeds set point FLOW: yellow flashing LED; low pump flow LOW BAT: red LED; D-cell batteries need to be replaced <b>-AND-</b> HVPS: red LED illuminates to indicate a malfunction with the high voltage power supply (HVPS) used to bias the ionization chambers
EXTERNAL CONNECTIONS	miniature DIN plug with RS232 serial data output for tritium measurement, and alarm status
DUST FILTERS	in line disposable cartridge, Pall P/N 12082
SAMPLING SYSTEM	6 hose barb ports are located on the front panel
PUMP	miniature internal pump for 3 to 5 volume changes per minute

## TECHNICAL SPECIFICATIONS, MODEL RS400-HTO, continued

IONIZATION CHAMBER VOLUME	effective volume: 400 cm <sup>3</sup> port to port volume: 440 cm <sup>3</sup>
POWER	<b>Alkaline Battery Option</b> Requires two "D" size batteries Alkaline type with external jack for supplementary power input
ENVIRONMENTAL	0° C to +40° C 20 to 90 % R.H. Non-Condensing
CASE	light weight aluminum
SIZE AND WEIGHT	7.6" L, 5.2" W, 6.9" H excluding handle, 6.5 lbs (3 kg)
ACCESSORIES	<ul style="list-style-type: none"><li>• 2 "D" size batteries, Alkaline type, removed from battery compartments during shipment</li><li>• Sniffer hose</li><li>• Dust filter</li><li>• 2.3 meter long cable for RS232 serial data. Mini-DIN plug for J2 output connector at one end with DB9 plug for serial connection on other end</li><li>• Power converter 100-240 VAC, 50/60 Hz, .25 A to 3.3 Vdc @ 1.2 A 5.5 mm O.D. x 2.1 mm I.D. Plug Center pin is positive</li></ul> <p><b>DO NOT SUBSTITUTE, use only the recommended power supply</b></p>

### ADDITIONAL ACCESSORY ITEMS FOR RS400-HTO VERSION:

- 2 each, desiccant column for HT-HTO measurement; while one is being used the other may be regenerated
- 1 each, dust filter P/N 12082, a second dust filter for the inlet to the downstream chambers when using the desiccant
- 2 each, mounting clips for desiccant column, location to suit customer
- Additional sniffer hose and fittings for making all hose connections to the desiccant columns

### 3.0. CIRCUIT DESCRIPTION



**CAUTION:** This instrument has not been designed for indiscriminate opening or disassembly of the internal parts. Electrostatic charge from the bias voltage on the ionization chamber cans will be present even when the instrument is switched OFF. The detector pre-amp contains highly sensitive semiconductors which are destroyed by even the slightest electrostatic discharge.

### 3.1. IONIZATION CHAMBERS

In its simplest form, an ionization chamber is an enclosed volume with two electrodes. Voltage is applied between the electrodes, generating an electric field, which will segregate and collect electric charges, which are created by nuclear events occurring inside the chambers. Nuclear events may consist of ionization of air molecules by external or internal alpha, beta or gamma radiation.

The RS400 monitors are designed to measure tritium. Activity of tritium decay is such that a concentration of  $1 \mu\text{Ci}/\text{m}^3$  in a volume of one liter will generate an ionization current of about  $0.95 \times 10^{-15}$  amperes. This is a very weak current.

Alpha pulses from naturally occurring radon, are much more energetic, they can produce short current bursts of up to  $10^{-13}$  coulombs during decay, and therefore appear as large noise "spikes" which can seriously impair tritium measurement.

Gamma radiation also has a strong effect. In practice, a gamma radiation field of 1 mR/hr will create the same amount of ionization as  $90 \mu\text{Ci}/\text{m}^3$  of tritium.

A tritium monitor, in order to measure to low concentrations, must be able to respond only to tritium and be immune to alpha or gamma radiation. For this purpose, a second ionization chamber system has been included to balance out any ionization current contribution from external gamma radiation.

In the RS400 instruments, the four ionization chambers are arrayed in a cruciform pattern, ensuring almost perfect gamma compensation in all directions and even for high gradient non-uniform fields.

The ionization chamber polarizing voltage is supplied by an electronic high voltage power supply. The surfaces of the ionization chambers have a thin coat of paint for insulation, but it is best to avoid touching them.

### 3.2. ELECTROMETER

Also known as a transimpedance amplifier, it serves the purpose of converting the extremely feeble ionization current into a voltage suitable for further signal processing and measurement display.

The heart of the electrometer consists of a specially selected dual ultra high impedance semiconductor device which has been chosen both for ultra low internal current leakage as well as long term d.c. stability. The semiconductors used in the RS400 instruments are suitable for measurement of currents as low as  $10^{-16}$  amperes.

In the RS400 instruments, the electrometer is directly attached to the ionization chamber cluster and is protected by a rectangular metal cover.

### 3.3. SIGNAL PROCESSING AMPLIFIER

A single printed circuit board attached directly to the front face of the instrument contains all power supply and signal processing electronics.

Proprietary circuitry is used for the recognition and elimination of transient signals due to radon or high-energy cosmic ray pulses. The RS400 instruments, with digital display, use a dedicated internal circuit to disable the pulse rejection circuit when the measured signal reaches approximately 80-100  $\mu\text{Sv/hr}$ .

An OFFSET control is furnished in order to adjust the reading to zero in case of offsets caused by tritium contamination of the chambers or otherwise.

A front panel control has been provided for adjustment of the set point (level) at which the acoustic alarm is desired to sound. The acoustic signaler has the second function of alerting the user that sample gas flow is impeded.

All power supplies are regulated. A warning LED on the front panel will illuminate red when the battery terminal voltage has dropped to about 2.2 V. This signals that the batteries should be replaced – WITHIN 1 HOUR AFTER THE WARNING LED ILLUMINATES. It will also illuminate when the high voltage power supply (HVPS) operates outside of specified voltage range.

Two plug and jack connections are found on the sides of the instrument. One is for an external power, and the other is the RS-232 cable connection to a personal computer.

## 4.0. CONFIGURATION

### 4.1. EXTERNAL FEATURES

The front panel features include:

1. the digital panel meter, 1 to 19,999  $\mu\text{Sv/hr}$
2. function control knob
3. alarm level control knob, 2 to 1,000  $\mu\text{Sv/hr}$
4. red LED; dual function; low battery, indicates when the D-cell batteries need to be replaced and indicates red if the high voltage power supply (HVPS) has a malfunction
5. signal level alarm LED
6. low flow alarm LED
7. acoustic signaler
8. mute push-button
9. calibration potentiometer (under phillips head screw)
10. offset potentiometer (small knob)
11. six sample hose barbs
12. two D-cell battery compartments

Side features include:

13. jack for external charger, 3 to 3.3Vdc, 1.2A-3A, **DO NOT SUBSTITUTE, use only the recommended power supply**
14. 8-pin mini-din receptacle for RS232
15. GAMMA CHECK label for position of check source, refer to section 6.0.
16. snap holder for dust filter

### 4.2. HOSE CONNECTIONS

The instrument may be operated in either of two modes. In the first mode, the instrument will respond to any radioactive gas passing through the instrument as well as tritium. In the second mode, it will respond only to HTO, even in the presence of other radioactive gases. The external plumbing (hose attachments) is selected to suit the mode in use.

FIRST MODE (refer to Figure 2) Measures total tritium plus any noble gases when present

A sniffer hose is attached to a small in line dust filter, which is directly attached to the "IN" hose barb. The other measurement chamber hose barb is routed to the inlet of the pump by means of a short piece of hose. Connecting a short loop of hose to each hose barb closes off the compensation chambers hose connections.

SECOND MODE (refer to Figure 2) Measures HTO only with noble gas compensation

In this mode, the exhaust from the measurement chambers is connected to a desiccant cartridge. The exhaust end of the desiccant cartridge is connected to a second dust filter and then to the inlet of the compensation chamber. The other compensation chamber hose barb is routed to the inlet of the pump by means of a short piece of hose. In this mode, the sample stream passes first through the measuring (upstream) chambers, and then through the desiccant cartridge, it continues through the compensation (downstream) chambers and finally exits via the pump.

**Note 1: Never Operate The Instrument Without A Dust Filter In The Sample Stream**

**Note 2: The Instrument Must Be In Thermal Equilibrium With Its Surroundings.**

**Note 3: To Avoid Erratic Response, The Pump Must Always Be Placed Downstream Of The Last Ionization Chamber In The Sample Path.**

## 5.0. OPERATION

Ensure that a dust filter is connected in line ahead of this instrument flow inlet in use. The following steps are necessary and sufficient to operate the instrument:

1. Set measurement alarm level to desired value.
2. Rotate mode switch to "MEASURE". The "low flow" LED will flash, since the pump is inactive. The "mute" switch will silence the intermittent tone if desired.

Allow 30 seconds for the instrument to be ready to sample. **Allow an additional two to three minutes for the instrument to stabilize.** Readjust (if necessary) by turning OFFSET control knob to achieve a zero reading on the meter

**NOTE: The rotation direction for the adjustment is clockwise for change in a positive direction. Use very small amounts of rotation, the display will not react immediately because there is a 30 second time constant.**

The instrument is now ready for use. In this mode the ionization chambers are active, but the pump is not. The instrument is in a so-called "standby mode" ready to sample the instant the mode switch is advanced to the next position.

3. Rotate the mode switch to the sample position. Now, the pump is operating and the low flow indication will be eliminated.

If it is desired to operate the instrument continuously on an external power supply, only a source of 3.3VDC, 1.2-3A current capacity should be used. Attaching the external power plug will automatically disconnect the D-cell batteries.

**NOTE: If the audible alarm is an intermittent tone, sample flow through the chambers is below specification. This could be an obstructed sampling hose or other**

It is IMPERATIVE that the sample stream be free from dust, dirt or moisture. Not only will the instrument show erratic behavior, but also it may cease to function entirely. If moisture is ingested, then continued pumping to evaporate and expel the moisture can be attempted. If this fails, the instrument must be returned to the factory for service.

Condensation can occur if an instrument is brought from a cold environment into warmer surroundings.

Furthermore, temperature changes to the instrument, both lower to higher as well as higher to lower will create transient currents in the electrometer which can appear as large phantom measurement signals.

The instrument must be allowed to thermally equilibrate to its surroundings prior to use. When there is an OFFSET due to thermal disequilibrium, use the following procedure:

### OFFSET COMPENSATION:

1. Switch the instrument into the measure model.
2. After approximately three minutes. The instrument should indicate 0000 on the digital panel meter. An offset of 5-7  $\mu\text{Sv/hr}$  is typical for situations due to temperature changes. This offset should disappear as thermal equilibrium is attained.
3. Adjust the "offset" compensation potentiometer as required. The location is shown in Figure 1.

**NOTE:** The rotation direction for the adjustment is clockwise for change in a positive direction. Use very small amounts of rotation, the display will not react immediately because there is a 30 second time constant.

### GENERAL OPERATION NOTES:



**NOT SUITABLE FOR USE IN WET LOCATIONS**

**NOT SUITABLE FOR USE IN EXPLOSION HAZARD ENVIRONMENTS**

The following information is provided to the user to ensure stable and accurate performance.

The monitor can be located on any flat surface, such as a table top, or, it can be mounted to a wall bracket or shelf, or on a small moveable cart. In all cases, the instrument must be protected against vibration, shock, moisture and dirt.

### ELECTRICAL GROUNDING

The electrical and electronic equipment grounding is often considered only from the viewpoint of hazard and safety. Indiscriminate or excessive grounding may actually enhance the potential of danger and disturb the proper internal operation of the instrument. The electronic circuitry, including logic, adjustment controls, local and remote displays, are centrally and all inclusively grounded at the ionization chamber module. The circuit system common line is electrically connected to the metal frame or housing of the electrometer module. When signal outputs are connected to remote displays, computer interfaces, or similar devices, it is necessary that no significant ground potential differences exist between the monitor and other equipment. If significant potential ac or dc differences exist, shifts in the instrument "zero" can appear.

### THE FOLLOWING IS RECOMMENDED

1. Make all interconnections. Normally the instrument operates on (2) "D" cell batteries. If it is desired, the instrument can operate continuously by connecting to the AC power converter provided. Use only the AC converter that is provided. Activate the instrument. Allow ten minutes "warm-up". Adjust zero if needed.
2. Attach remote connections (devices) and verify absence of change in zero.

If zero has changed, check for ground loops and spurious ac or dc potential differences from one location to the other.

## RS232 OUTPUT

The RS232 interface serves the purpose of transmitting data to any digital computer via a standard 2 wire RS232 link.

The data includes:

The tritium measurement level, status for level and flow alarms, alphanumeric information representing location and identification for the instrument.

With a personal computer use Hyper Terminal or another suitable application to view the data. The COM Port setting should be 9600 baud, 1 start bit, 8 data bits, parity = none, 1 stop bit, and flow control = none. The tritium monitor is capable of transmitting data only. The data is illustrated below. There are eight fields with single spaces between the fields. The data string is terminated with "\r\n".

The data string appears as shown below followed by an explanation of each field.

:A0F1 000421 uSv/h.. 004199 L0H0 0090 1.10 00000523

Field 1 (A0F1):

: = start character

A = "Alarm" (high tritium alarm)

0 (no alarm) or 1 (alarm)

F = "Flow Alarm"

0 (flow is OK) or 1 (low flow – blocked filter, bad pump, or blockage)

Field 2 (000421): Tritium value

Field 3 (uSv/h.): Tritium unit of measure

Field 4 (004199): Serial number of instrument

Field 5 (L0H0): L = "Low voltage power supply alarm"

0 (voltage is OK) or 1 (voltage is low)

H = "High voltage power supply alarm"

0 (voltage is OK) or 1 (voltage is low)

Field 6 (0090): Approximate percentage of battery remaining (90%)

Field 7 (1.10): Microcode version

Field 8 (00000523): Sequence number

## **6.0. CALIBRATION**

### **6.1. METHOD**

Tritium monitors employing ionization chambers, such as the 400 series portable instruments may be calibrated with either of two methods.

The first method consists of injecting a known activity of tritium gas; the second method uses external gamma radiation of known field strength.

To ensure traceability to National Standards, the first method must be employed. This method is time consuming, and is quite difficult to perform with precision. This first method is, however, useful as a "type" test, and can serve as a basic accurate calibration from which the gamma response (the second method) can be cross-correlated.

The second method uses an external gamma field. In this instance, the polarization of the compensation ionization chambers is reversed to coincide with that of the measurement ionization chambers.

In this condition, the effect of external gamma radiation now adds rather than cancels, and a known gamma field should produce a predetermined measurement indication.

### **6.2. GAS CALIBRATION**

Since the instrument is essentially linear, a relatively high concentration can be used for most accurate results. Values between 100 – 1,000  $\mu\text{Sv/hr}$  are convenient, but any other values from 20 – 5,000  $\mu\text{Sv/hr}$  can be used.

The manufacturer of the gas calibrator generally provides instructions for the use of gas calibrators, and these should be followed.

Some general hints can be given.

It is important that the calibration sample be well circulated through the entire calibration system loop.

Adequate time should be allowed for the system pressure and temperature to come to equilibrium, and that no excess pressure is built up.

The inclusion of a previously calibrated "master" or "reference" tritium monitor in the sampling loop is highly recommended.

The calibration can actually be repeated for several levels of tritium activity. This is not done to verify the linearity of the tritium monitor (which is highly linear) but to ensure that the calibration process itself is free from subtle errors.

### 6.3. GAMMA CALIBRATION

If the unit has previously been calibrated with tritium gas, then it is sufficient to use a gamma radiation source to produce a response when placed at a specified location relative to the instrument under test. Lead shielding is advised since the compensation chambers will cancel the measurement. It is best to shield both of the compensation chambers plus one of the measurement chambers. Use a minimum of ½" thick lead. For the highest value response, the gamma source should be directed through the bottom of the case to minimize interaction with the compensation chambers. If the gamma source is long lived, no chronological correction is needed. To verify calibration at a future date, the original gamma source must be used. Records must be kept to identify relative location of the source and the expected result. Be sure that temperature and pressure variations are taken into account.

If calibration by either of these methods is performed, and the instrument response is somewhat different from the expected value, then small adjustments can be made by turning the calibration potentiometer with a small screwdriver. The calibration potentiometer is accessed by removing the small Phillips head screw on the front panel located above the label **CAL**.

Large changes in calibration are evidence of malfunction. The factory should be consulted immediately.

OVERHOFF TECHNOLOGY CORPORATION  
Telephone (513) 248-2400  
Facsimile (513) 248-2402  
Email: [support@overhoff.com](mailto:support@overhoff.com)

### 6.4. GAMMA CHECK

If a tritium monitor has previously been calibrated by any other method, gas or gamma, a low intensity gamma radiation source check can be used as a quick verification of monitor performance. On the left side of the instrument case towards the front which is the defined location for "**GAMMA CHECK**". When using the identical gamma check source, at the defined spot, it should always produce the same instrument response, provided, of course, temperature and pressure variations are taken into account. This source check may be performed at a frequency of your choice, it could be daily, weekly or monthly. We recommend a low intensity gamma check source of the type which is commonly intended for G-M counters or other survey instruments. For example; a 10 micro Curie, Cesium-137 check source should be sufficient for a monitor reading of 100-200  $\mu\text{Sv/hr}$ .

**IMPORTANT:** Do not adjust the calibration when performing a gamma check.

## 7.0. MAINTENANCE

Overhoff 400 series portable instruments have been designed for many years of trouble free service. Very little maintenance is required, but some periodic attention may be necessary, especially if the instrument is to be used in adverse environments.

Pump life is in excess of 1000 hours of actual use; ensuring that the instrument is operated only with dust filters in line preserves its life.

When not in use, the monitor should be stored in a cool dry environment.

### OPERATOR MAINTENANCE

The following operational checks may be performed at daily, weekly or monthly intervals to suit.

Inspect dust filter for excessive dust build up. Check the flow rate. Does the pump have sufficient flow such that the Low Flow Alarm is not indicated when 10ft of the sniffer hose is connected to the inlet of the dust filter?

**GAMMA CHECK**, If a tritium monitor has previously been calibrated by any other method, gas or gamma, a low intensity gamma radiation source check can be used as a quick verification of monitor performance. On the side of the instrument case towards the front which is the defined location for "**GAMMA CHECK**". When using the identical gamma check source, at the defined spot, it should always produce the same instrument response, provided, of course, temperature and pressure variations are taken into account. This source check may be performed at a frequency of your choice, it could be daily, weekly or monthly. We recommend a low intensity gamma check source of the type which is commonly intended for G-M counters or other survey instruments. For example; a 10 micro Curie, Cesium-137 check source should be sufficient for a monitor reading of 100-200  $\mu\text{Sv/hr}$ .

**IMPORTANT:** Do not adjust the calibration when performing a gamma check.

Manipulate the alarm set point to verify correct functioning of the alarm.

If the instrument is suspected of DRIFT, the zero reading may be verified. This should be done by an instrument engineer or technician.

### SUPERVISORY MAINTENANCE

The following tasks are the responsibility of the supervisory engineering staff.

1. Calibration verification is to be performed at yearly intervals, or as otherwise specified.
2. Response checks (in case of need for cursory verification of the operational status of the ionization chambers and of the whole system), of the system may be tested by using a low strength gamma radiation check source. This must be done under the strict supervision of a health physicist. The gamma source is brought into proximity of each ionization chamber and the response is observed.

### FACTORY MAINTENANCE

A determination that the system appears to have suffered a functional failure should require that the factory be notified (telephone (513) 248-2400, facsimile (513) 248-2402). Engineering assistance via telephone or facsimile, will be supplied by the manufacturer OVERHOFF TECHNOLOGY CORPORATION.

Should it appear to be necessary to return the instrument to our factory, authorization for the return must be obtained from Overhoff Technology Corporation prior to shipping. In-freight charges will be borne by the customer.

## 7.1. D-CELL BATTERY REPLACEMENT

The Model RS400-HTO with optional Alkaline batteries uses (2) "D" size Alkaline batteries. The batteries will need to be replaced within an hour after the low battery light illuminates.

**NOTE: Remove the batteries before shipment or inactive storage of more than 30 days**



This instrument contains components that are easily destroyed if the case is opened and handled without proper precaution. If damage occurs, the repair will not be covered under warranty. Avoid touching the ionization chambers and the PC Board Assemblies to reduce the risk of damage.

## 8.0. SERVICE AND SUPPORT

This instrument contains highly sensitive semiconductors which are destroyed by even the slightest electrostatic discharge if the case is opened and the instrument is handled without proper precaution.

Special training can be given to qualified technical personnel who are entrusted with instrument service and repair responsibility.

Warranty is void if maintenance or repair (other than that which is listed in this manual) is performed by an unauthorized repair facility.

OVERHOFF TECHNOLOGY CORPORATION  
Telephone (513) 248-2400  
Facsimile (513) 248-2402  
Email: support@overhoff.com

## 9.0. WARRANTY

All instruments built by Overhoff Technology Corporation are warranted to perform as claimed.

Defective components or workmanship of the instrument will be corrected free of charge for parts or labor within a period of one year from delivery. Nonperformance of the instrument as a result of negligence on behalf of the customer is not covered by this warranty.

Should it appear to be necessary to return the instrument to our factory, authorization for the return must be obtained from Overhoff Technology Corporation prior to shipping. In-freight charges will be borne by the customer.

## 10.0. REPLACEABLE PARTS

The following parts and components are disposable items and may be obtained from Overhoff Technology Corporation or from any original supplier:

Battery, "D" size, alkaline	P/N EN95,(qty 2 req'd)
Dust Filter	P/N 12082
Ionization Chamber Can	P/N 1020686
Pump	P/N 50084
Hose Barb, Sample Inlet	Brass, P/N 22BH-4-2
Hose Barb, Sample Outlet	Brass, P/N 230-4-2
Panel Meter	P/N DMO-742W
AC power converter	P/N KTPS05-03315U-VI-P1 Input: 100-240 VAC, 47-63Hz, 0.25A Output: 3.3 Vdc @ 1.2A, Output Plug: 5.5 mm O.D. x 2.1 mm I.D. Plug Center pin is positive

**DO NOT SUBSTITUTE, use only the recommended power supply**

Fuse, 2 Ampere	P/N MDL-2
RS232 Cable	P/N J2-RS400-2M (2.3 meter length cable is standard, a maximum length of 15 meters is available)
Desiccant Cartridge	Drierite P/N 26800
Mounting Clips for above	Drierite P/N 26809
Replacement Desiccant	Drierite P/N 23005 ( 5 lb jar)






FIGURE 1  
FRONT PANEL CONTROLS  
MODEL RS400-HTO




HOSE CONNECTIONS  
FOR TOTAL TRITIUM MEASUREMENT



HOSE CONNECTIONS  
FOR NOBLE GAS COMPENSATION

FIGURE 2  
HOSE BARB CONNECTIONS  
MODEL RS400-HTO




8 PIN MIN DIN CONNECTOR  
 LOOKING AT RECEPTACLE FROM  
 OUTSIDE OF INSTRUMENT


**OUTPUT CONNECTIONS FOR MODEL SERIES RS400 AND RS400-HTO**  
 APPLIES TO MONITORS BUILT AFTER SEPT. 2013 WITH P.C. BOARD No. 400ACMB.R1

FIGURE 3  
 OUTPUT CONNECTIONS  
 MODEL RS400 AND RS400-HTO

REVISIONS			
REV	DESCRIPTION	DATE	APPROVED
0	RELEASED FOR PRODUCTION	DW	04-14-10



J2 OUTPUT CONNECTOR 8 PIN MINI DIN PLUG	
NO CONNECTION	1
NO CONNECTION	2
COMMON	3
NO CONNECTION	4
NO CONNECTION	5
RS232 Tx OUTPUT	6
NO CONNECTION	7
RS232 Rx INPUT	8




9 PIN D CONNECTOR PLUG WITH FEMALE CONTACTS	
1	NO CONN
2	RS232 Tx OUTPUT
3	RS232 Rx INPUT
4	NO CONN
5	COMMON
6	NO CONN
7	NO CONN
8	NO CONN
9	NO CONN


NOTE: THE SHIELD IS CONNECTED TO COMMON WHEN THE CABLE IS ATTACHED TO THE J2 RECEPTACLE

**J2 OUTPUT CABLE  
RS232 CONNECTIONS FOR MODEL RS400 AND RS400-HTO**

		<b>OVERHOFF TECHNOLOGY CORPORATION</b>		MILFORD, OHIO 45150 U.S.A.	
		2 METER LONG J2 CABLE FOR MODEL RS400 AND RS400-HTO			
DRAWN D.WILLIAMSON	DATE 04-14-10	SIZE A	FILE NAME J2-RS400.DWG	DWG NO. J2-RS400-2M-L.COM	REV 0
APPROVED D.WILLIAMSON	DATE 04-14-10	SCALE .66	SHEET 1 OF 1		




FUNCTIONAL BLOCK DIAGRAM  
OVERHOFF MODEL RS400-HTO  
with ALKALINE BATTERY OPTION




TOP VIEW  
FRONT PANEL

NOTES:


- Dimensions: Inches[mm], FOR REFERENCE ONLY
- Weight: 6 lbs. (2.7kg)
- MODEL RS400-HTO, Dwg No.1021476,  
Description: quad (gamma compensation) 200 cm<sup>3</sup> chambers (nominal volume)  
Measurement range: 1 - 19999  $\mu$ Sv/h  
Display: 4½ digit LCD indicates 1 - 19999  $\mu$ Sv/h
- Includes these Standard Features:
  - J2 Connector Receptacle with RS232 Outputs
  - Electronic High Voltage Power Supply
  - Pump Control Circuit Board
  - Dual mode hose connections:  
Mode 1: Use the upstream chambers to measure total tritium plus noble gases.  
Mode 2: Use the upstream chambers, a desiccant column (supplied as a separate accessory) and the downstream chambers in order to discriminate noble gases and measure HTO only.
- Includes these Optional Features:
  - Alkaline "D" Cell Batteries




TOP VIEW  
CHAMBER POSITIONS



LEFT SIDE



FRONT VIEW



SECTION VIEW  
RIGHT SIDE

Important Safety Information in Manual

REVISIONS			
REV	DESCRIPTION	DATE	APPROVED

MODEL RS400-HTO PORTABLE TRITIUM MONITOR		<b>OVERHOFF TECHNOLOGY CORPORATION</b> MILFORD, OHIO 45150 U.S.A.		
GENERAL ARRANGEMENT, TRITIUM MONITOR MODEL RS400-HTO MODIFIED FOR ALKALINE BATTERIES				
DRAWN J. CREECH	DATE 07-09-18	SIZE B	FILE NAME 1021476-3915-1.DWG	DWG NO. 1021476
APPROVED D. WILLIAMSON	DATE 07-09-18	SCALE N/S	REV 0	
SHEET 1 OF 1			REV 0	